

3.5 PROGRAM SETTING

SETTING INTERFACE

SPEED [REDACTED] R/min

SPEED SETTING

- Under standby model, press together to enter the setting page.
- Press at **0001** to enter the speed setting page.
- Press or to adjust the speed.
- Press to confirm.

TIMING SETTING

- Under standby model, press together to enter the setting page.
- Press at **0002** to enter the timing setting page.
- Press or to adjust the timing.

※ ① For example: **003.5** means the pump will turn off after 3.5 hours.
 ② Timing setting repeats every time after power-off, unless adjust to **999.9** to cancel.
 ③ Countdown will pause when press STOP bottom.


- Press to confirm.

3.4 LIGHT INDICATION

LIGHT	BEHAVIORS	CAUSE
	<ul style="list-style-type: none"> Light off 	<ol style="list-style-type: none"> No power input: <ol style="list-style-type: none"> Power line has a break (open circuit) PV+ and PV- terminals wrong connected Controller power system damaged Fuse has blown.
VOLTAGE [REDACTED] VDC	<ul style="list-style-type: none"> E001 E002 E003 E999 	<ul style="list-style-type: none"> Under-voltage protection Over-voltage protection Over-temperature protection (70°C) Default phase (open circuit) UVW wires short circuit

※ Restarts automatically after protection.

3.3 LABEL DESCRIPTION



ITEM	DESCRIPTION	FUNCTION
<ul style="list-style-type: none"> ● DC ○ 24V ○ 36V ○ 48V ○ 60V ○ 72V ○ AC ○ 90V ● 110V ○ 120V ○ 220V ○ 300V 	VOLTAGE	<ul style="list-style-type: none"> Controller Model=Rated Voltage
	INDICATOR LIGHT	<ul style="list-style-type: none"> Power: Light on=Power connected GPRS: Flickering every 3s=Not connected Flickering every 1s=Connected MPPT: Flickering=MPPT Mode On Well: Light on, water level under sensor level Tank: Light on, water level reach TH level
	SPEED CONTROL	<ul style="list-style-type: none"> Program Setting Push to Adjust Speed or Timing
	RUN / STOP	<ul style="list-style-type: none"> Push to RUN or STOP Push to Confirm
POWER [REDACTED] Watt	POWER	<ul style="list-style-type: none"> Display Input Power
VOLTAGE [REDACTED] VDC	VOLTAGE	<ul style="list-style-type: none"> Display Input Voltage Display Error Code
SPEED [REDACTED] R/min	SPEED	<ul style="list-style-type: none"> Display Motor Speed Display CPU Temperature GOXX